

AVBP Assembly Instructions



Remove end caps & slide extrusion into center of the channel and back of base. Tighten with Allen key and replace end caps.



If using standard mount(s), place in desired location and tighten each screw.



If using a tilting mount, twist rod until mount is in desired position and place mount down into pole.



Tilt mount to desired angle and tighten screws to secure.



Tighten top screw to secure rod in place.



Attach acrylic bracket with angle tilting up to desired position on each pole with provided screws.



Attach pocket through the acrylic bracket using the thumb screws. Repeat last 2 steps for other pocket.



After attaching bracket to television(s) with provided screws, line up holes with mount(s) and slide into place.