



## Parts List

- A. (1) Snap frame
- B. (2) Riser
- C. (2) Ceiling mounted pate
- D. (2) M6x30 Socket headcap screw
- E. (1) S4 Allen wrench
- F. (1) Drill template
- G. (6) 4x20 Pan head tapping screw
- H. (6) Plastic plug
- I. (2) Metal pad
- J. (2) M6x50 Hexagon screw
- K. (1) S5 Allen wrench

## Step

1. Using Allen wrench E to connect B and C by screw D.
2. Stick paper F to the ceiling where you want to mount the unit.
3. Screwing C to the ceiling by G. If the ceiling is the concrete, using the H please. Attach I to the back inner edge of the snap frame with hole aligned. Screw J with frame though hole on I and pre-drilled hole on the frame.