



# DISPLAY CUBE

## Assembly Instructions

PANELS			HARDWARE BAG							
A	Top Panel	1 pc	H1	Cam Lock	16 pcs		H2	Cam Post	16 pcs	
B	Side Panel	2 pcs								
C	Front Panel	2 pcs								
D	Bottom Panel	1 pc								

**Attention:** Before you start assembling your cube; please prepare a soft surface work area on the floor. The only tool you will need is a screwdriver. Carefully remove all hardware from packaging and place the hardware parts on the soft work area where they will not come in contact with the laminated wood components. To avoid damage to the laminated wood surfaces, keep hardware parts separated until they are needed for assembly.

### How to use Cam Locks and Cam Posts:

1. Insert Cam Posts into the white holes on boards B and C . Use screwdriver to tighten the Cam Posts. Do not over tighten.
2. Fit the hole in the edge of the joining board over the Cam Post .
3. Insert the Cam Locks into the round cutouts on boards B and D so the groove at the back of the Cam Lock fits the head of the Cam Post .
4. Tighten the Cam Lock until it snugly engages with the Cam Post. Do not over tighten.

