



©2005 George Patton Associates, Inc.

Hardware Required:

- (1) allen wrench
- (2) 6mm x 2"
screws
- (4) #6 x 5/8"
screws

Here is your new MBSTAND.

Please follow instructions.

Using the (2) 6mm screws and the allen wrench connect the base to the pole.

Use the (4) #6 screws to attach the literature tray to the top of the pole using a phillips head screwdriver.