

# BannerFlex® Messenger® GMS

## ASSEMBLY INSTRUCTIONS

Installation Hardware provided:  
4- 5/8" washers, 4- lag shields, 4- 3/8" lag bolts.

1. Place template over mounting surface at desired location. Use the color coordinated outlines as a guide, dependant on width of unit.
2. Mark bolt locations through the paper and onto mounting surface, 2 per side. Installer needs to drill 5/8" holes into mounting surface.

