


Universal Tablet PC Stand (with Lock Function)

FEATURES:


1. Universal stand/holder for Tablet PC, especially ideal for Apple's iPad 1/iPad 2.
2. Can easily hold Tablet PC with rotating 360° angles.
No worry about slipping off the hands.
3. Non-slip Silicone padding prevents Tablet PC from being scratched when set on plastic stand.
4. Frame Mounting way supporting 15° tilt (wrist-friendly angle for surfing, typing and more).
5. Adjustable stand- easy to get optimum viewing angle and allow user to use tablet in portrait, landscape and keyboard positions.
6. Setting with thin strap can firmly be used on the back of headrest.
7. With particular computer locks, prevent Tablet PC from thievery in public places (such as school, dormitory and company etc. places)




INSTRUCTION: The preset status is released.

1. HOW TO SET/ADJUST:

- STEP 1:** Set Tablet PC into the frame and press downward till getting optimum size (height and width). Continuously, rotate the wheel (B) to left in order to adjust the thickness and make the interval less. (Note: Oppositely, rotating the wheel (B) to right is to make the interval more.)




- STEP 2:** If user needs to readjust or take away Tablet PC from the frame, rotate the wheel (B) to right to make the interval more and then push the release button (A) outward. The frame will be sprung.




2. HOW TO USE

- USE 1:** Put the finger through the plastic ferrule (C)
User can easily hold Tablet PC with rotating 360° angles and no need to worry about slipping off the hands.
- USE 2:** Turn the plastic ferrule (C) to be horizontal to the table.
Mounting way can support 15° tilt and user can freely choose vertical or horizontal viewing holding.
- USE 3:** Can put the thin strap through the plastic ferrule (C) and then set on the back of headrest.
Hold Tablet PC in portrait and landscape modes.




3. HOW TO SET-UP STAND:




Assembly: Base (A1), Support (A2), Screw (A3), Non-Slip Silicone Pad (A4). A4 is no longer needed, it is built into the model.

- STEP 1:** The preset status of base (A1) and support (A2) etc. assembly are offered separately. User must rightly press the support (A2) into the base (A1) through the latch (D). And then turn the screw (A3) to tighten it in order to make the join of base (A1) and support (A2) steady. Finally, cover the bottom of base (A1) with Non-Slip Silicone Pad (A4). The stand is ready. (Note: Make sure to press the support (A2) into the base (A1) to the end rightly before turning the screw (A3).)
- STEP 2:** After hold the frame upright, let the trench (a) of the plastic ferrule (C) upward. And then invert the frame and make the salient point (b) of the stand connect with the trench (a) of the plastic ferrule (C).
- STEP 3:** Turn the frame 180° back to front side. The trench (a) of the plastic ferrule (C) will be up again. From now on, the frame won't be removed from the stand directly. (Note: prevent the frame from being removed easily so need to remove from opposite side)



4. HOW TO ADJUST VIEWING ANGLE:

- Slide the button (c) downward and hold it in order to adjust particular viewing angle. After getting optimum viewing angle, release the button (c). The viewing angle is ready.



- HOW TO LOCK:** With particular computer locks, prevent Tablet PC from thievery in public places (such as school, dormitory and company etc. places)

- STEP 1:** Make sure you get an optimum computer lock and if the adjustable latch (E) put back rightly. (Note: before lock it, please make sure if the adjustable latch (F) put back rightly. Prevent the slot from being damaged with forced power.)
- STEP 2:** Insert the particular computer lock into the slot and then rotate 90° to the left. The lock is locked.
- STEP 3:** No matter whether there is the stand to go with the frame. User can lock their Tablet PC anywhere and prevent it from thievery.

