



Menu Power Bank User Manual

Product Image :




- ① Charging Indicator
- ② Switch Button
- ③ Alu. body
- ④ USB Output Port
- ⑤ Input Port
- ⑥ USB Output Port
- ⑦ Acrylic Holder
- ⑧ Wireless charging area

Poster Inserting Instruction :



Acrylic Holder Mounting Instruction :



Switch Button Indication

- Press once to turn on the power bank, and LED indicators will lit.
- Press twice to switch off the power bank.
- When the power bank working, to press 5 seconds continuously, the led lights for menuholder working; To press another 5 seconds continuously, the led lights stop

Notes :

- please fully charge the power bank when using it for the first time.
- please check whether the charged device is working when using it, to ensure the power bank's normal running.
- please choose suitable charging wires when charging the power bank or to charge for your phones.
- The power is insufficient if all the LED lights are off, please charge the power bank timely.
- please pull up the charging wire to avoid wastage when your phones are fully charged.
- You may need to recharge the power bank when the power bank entering the protection condition for some reasons such as output short circuit (no reaction when you pressing the switch button).

Input: 5V $\overline{=}$ 2A | Output: 5V $\overline{=}$ 1A x 2
 Rated Capacity: 10000mAh, 36Wh



Made in China