


# SCTWRCOLBK Assembly Instructions



Begin by laying out all your pieces for easy access.




Remove floor levelers from all panels. Lay out the front panel and slide on both side panels, one at a time.



Use included screwdriver to tighten set screws.



Slide the door panel atop the two side panels.



Reattach all floor levelers. Use the included screwdriver to again tighten the set screws.



Carefully lift the showcase vertically with your assistant.



Fit the bottom cabinet's base into the case.



Fit the base of the showcase area into the case.



Insert light panel diagonally from inside case\*. Lower right rear corner (side with switch) to bottom lip, then lower left rear corner. Once both sides are in place, lower front side (panel opposite door). Connect wire output from showcase to light panel wires.



Place the top panel of the showcase so the holes line up with the lights for ventilation.



Insert the three tempered glass shelves. If needed, adjust height of shelf clips with included screwdriver.



Your showcase is now complete and ready to be filled with merchandise!

\*Please Note: Repetitive insertion of light panel may cause small chips to the laminate covering of the panel. These damages are small and are hidden once the panel is in place.