

Tension Fabric Instructions

1. Take out the fabric banner and all of the hardware pieces from the tote bag.



2. Insert the segments of the straight pole, which is held together with an interior bungee cord. Repeat on the second pole.



3. Match up the numbers on the segments.



4. Push the snap lock down and slide one segment into the next until the snap lock pops up and the frame is secure.



5. Repeat steps 3 and 4 until the frame is assembled.



6. Pick up one end of the frame and gently slide the banner onto the hardware.



7. Continue to slide the banner over the frame.



8. Secure the banner by zipping up the side zipper. It is easiest if one person pulls both sides of the banner taut while the other person zips the banner up.



9. Your Tension Fabric Display is fully assembled. Stand display upright.

