

ASSEMBLY INSTRUCTIONS

WHLNSTBK35

PARTS LIST

- A.Wood Top X1
 - B.Leg X4
 - C.Cap Nut X8
- *Wrench Not Included



**Note: Wrench
not included**

Flip over Wood Top (A). Secure Legs (B) to the wood top by using Cap Nut (C).



NOTE: Hardware may loosen overtime. Periodically check that all connections are tight.
Clean with soft, dry cloth. To protect finishing, avoid using chemicals and household cleansers.

DISPLHYSGO