

Portable Display Instructions



Step 1
Place ShowMax unit with wheels facing up and away from the front of the display table. Unlatch two panel latches and both bottom end cap latches.



Step 2
Open unit. Remove styrene header, lights and cords. Fold four end caps up.



Step 3
Grip each side of unit on outside near top of case, and lift up until case is vertical.



Step 4
Open outer panels, but leave angled to support display.



Step 5
Place header into two slots on backside of center panels.



Step 6
Mount light fixture by inserting base peg into hole on top of side panel.

Arch top header stores easily into back of unit. Another slot is available for a second header.



Hideaway handle retracts when presenting.

Easy storage for the halogen lights that are included with each unit.

Built-in literature storage space.



Inline skate wheels make for a smooth ride.