

Assembly Instruction

Step 1

Measure desired distance from floor to mounting bracket .
Place one Z-bar on the wall, use a bubble level to ensure the bracket is horizontal.
Mark hole locations through holes in Z-bar.

Step 2


Drill holes in the wall at marked locations.

Step 3

Securely mount one Z-bar to the wall using provided screws.
Z-bar can not be loose on the wall.


Step 4

Mount the other Z bar onto wooden boards on the back of the criss cross slatwall using screws.



Step 5

Repeat steps 1-4 for the bottom set of Z bars



Step 6

IMPORTANT: TWO PERSON LIFT!!!
Lift the slatwall just above the Z-bar on the wall. Push the slatwall to the wall and slowly lower it onto the Z-bar on the wall. A third person may help to visually check that the bracket on slatwall is seated on the mounting bracket on the wall before releasing slatwall.

